

Use **only** engine oil with Hastech Rocker Arms

(**No** cam lube, assembly lube, EP lube , moly paste, grease etc..)



Checklist for first start with new rocker arms:

- Camshafts are equal to Porsche quality
- Correct valve lash (completely cold): **0.10mm (0.004")**
- All oil holes are clean in the cam box oil bars
- **Break in camshaft:** **10 minutes @ 2500 rpm** do **NOT idle**
- Remove top valve covers and check for proper oiling on all camshaft lobes
- Re-check valve lash.